

# Contents

## Table of Contents

<b>Introduction</b>	<b>2</b>
<b>Use and Troubleshooting</b>	<b>3</b>
<b>Mode 3 Advanced Mode</b>	<b>4</b>
<b>Connection to a PC</b>	<b>5</b>
<b>Supported Device List</b>	<b>6</b>
<b>Using Advanced Mode</b>	<b>7</b>
<b>Disabling Signature Verification</b>	<b>9</b>

## **Attiny Fuse Repair User Guide for Version 3.X Firmware**

**The ATTiny Fuse Repair Programmer will restore your corrupted ATTiny device to factory defaults less than one second without the use of a computer.**

**Simple to use, there are only two possible outcomes. Yellow LED (ERROR) or Green LED (Success). It just doesn't get easier than that.**

**No more throwing away locked microcontrollers, just fix them all in a snap!**

**In this version of firmware, we have added the ability to program fuses in devices that are not in the supported devices list. As long as the device you are trying to restore uses the same High Voltage Serial Programming method, the programmer will work for you.**

**Also available is the ability to skip the erase command, leaving your code intact. Just simply install jumper J1 when the power is disconnected from the programmer, then power on the programmer. The fuse restore programmer will write the factory default fuses to your attiny and skip the erase function at the same time.**

**Please follow the instructions carefully. We are not responsible for any damage caused if the programmer is misused.**

To use the programmer, simply insert your ATTiny in the correct socket and connect power. Within one second either the green or the yellow led will illuminate. Green LED indicates success, Yellow LED indicates failure. Failure can be caused by a number of reasons.

1. You do not have the correct power supply. This is 99% the cause of all failures. Please use a 13.5 - 16 Volt DC power supply with positive center on the plug. It is very important that you measure the output from your power supply using an accurate voltmeter! We are not responsible if you damage the programmer, or anything connected to it. Incorrect voltage or polarity may cause damage to you and/or the programmer!
2. You are not inserting the chip in the correct socket. Please see the instructions in Table 3 below.
3. The device signature cannot be read. Is the device damaged? Is it inserted correctly?
4. The device is not supported. Please check the device list (Table 3) below. If the programmer does not reprogram your attiny and there are no led's illuminated, perhaps you have a damaged power supply. Once power is connected, the red led will illuminate to indicate power has been applied. If it does not, you are not using the correct power supply. If you are getting errors continuously ( yellow LED illuminated ) you can connect a MAX232 circuit to the debug port as shown in Fig 1 below.
5. Do you have jumper J1 installed? If the lock bits have been programmed and J1 is installed, the programmer will fail. The attiny must be erased if the lock bits have been programmed. Please remove jumper J1 and power cycle the programmer, and try again.


**Please Remember: This device is not designed to circumvent LOCK BITS!**

## Mode 3 Advanced Mode

New in Version 3, mode 3 or "advanced mode". This mode works with a terminal on your PC. It allows reading and writing of the fuse bytes. Also included is a new feature that disables signature verification, allowing the user to program fuses on avr devices that are not in the device list (Table 3).

**WARNING:** We are not responsible for damage caused by programming non standard fuse values. **KNOW WHAT YOU ARE DOING!**

**\*\*The fuse programmer supplies the MAX232 with 5 Volts.**



**Fig 1. Connecting the Programmer to the Computer's Serial Port**

When connected, the programmer will display fuse information or error messages to a terminal at 9600 baud.

**Hyperterminal settings:**

- Baud Rate: 9600,**
- Data Bits: 8,**
- Stop Bits: 1,**
- Parity: None,**
- Flow Control: None,**
- Terminal Emulation: VT-100 (ANSI).**

A low Cost Serial to TTL Converter can be found on our website [here](#).

<u>Attiny Fuse Repair Programmer</u>	<u>RS232toTTL Converter</u>
RX	RX
TX	TX
-	GND
+	VCC

**Table 1. Connecting the [RS232toTTL](#) module to the ATTiny Fuse Restore Programmer**

If you do not have a serial port on your PC, the programmer can be connected to one of our low cost [USBtoTTL](#) adapters found on our website [here](#). See Table 2 below for connection details.

<u>Attiny Fuse Repair Programmer</u>	<u>USBtoTTL Converter</u>
RX	TX
TX	RX
-	GND
+	5V

**Table 2. Connecting the Programmer to the Computer's USB Port using the [USBtoTTL](#).**

The ATTiny Fuse Repair Programmer supports the following devices:


<u>Socket U5</u>	<u>Socket U6</u>
<b>Attiny11***</b>	<b>ATtiny24</b>
<b>ATtiny12</b>	<b>ATtiny24V</b>
<b>ATtiny12V</b>	<b>ATtiny44</b>
<b>ATtiny12L</b>	<b>ATtiny44V</b>
<b>ATtiny13</b>	<b>ATtiny84</b>
<b>ATtiny13A</b>	<b>ATtiny84V</b>
<b>ATtiny13V</b>	
<b>ATtiny25</b>	
<b>ATtiny25V</b>	
<b>ATtiny45</b>	
<b>ATtiny45V</b>	
<b>Attiny85</b>	
<b>ATtiny85V</b>	

**Table3. Device List**


**\*\*\*While the ATtiny11 does not support ISP programming, this programmer will restore the fuses back to factory settings.**

## Using the Programmer

**If the programmer is connected to the terminal, and it is powered up with no devices inserted, you will see a screen like this:**



**If a device was inserted, you will see this message:**



**Pressing ESC gets you into MODE3 (Advanced Mode). You will then see a screen like this:**





**You now have Four Options:**

**1. Read Fuses.** Have you ever been curious to know what the fuse values are when your attiny device has been corrupted? Pressing "1" will show you the fuses. Then pressing any key will always return you back to the main menu.

**2. Pressing "2"** will allow you to program the fuses on any of the devices in the device list. If you would like to program any device NOT in the device list, you must select "4" (Disable Signature Verification) before pressing "2", Program Fuses.


**AGAIN, PLEASE Be careful here! NON Standard fuse values may cause unknown results preventing your device from entering programming mode, even with this programmer!!  
BE SURE YOU KNOW WHAT YOU ARE DOING!!**

If signature verification is disabled, the programmer does not know any information about the device it is trying to program. (i.e. The default fuse values, or whether or not the device has high, low or extended fuse bytes or all three).

When programming a device (i.e. a mature avr device such as the 90S series) you will be asked for all three fuse bytes. Even though the device has only one fuse byte, you must enter the same fuse byte for all three fuse bytes.

For example, you want to restore the SPIEN fuse on a AT90S2323 and disable the FSTRT fuse at the same time, enter hex value DF (not case sensitive) for all three values (high fuse, low fuse, and extended Fuse bytes). The device will ignore the extra fuse bytes. After programming, the fuse repair programmer will read back three fuse bytes. This mode does not work for restoring factory defaults since the information is unknown as to what the default values are based on the device's signature.

**The only way to Enable Signature Verification (if you disabled it) is to restart the programmer. (unplug power and reconnect). Signature verification is always enabled by default. When pressing "4" (Disable Signature Verification), you will see a screen like this:**



### **3. Factory Defaults selection "3".**

**Pressing "3" will restore the fuses to factory defaults, same as in standalone mode. If signature verification was disabled, it will be re-enabled by selecting factory defaults.**

**You can exit Advanced mode by powering off the programmer.**

**Any questions? Email us at: [microcontrollerprog@yahoo.com](mailto:microcontrollerprog@yahoo.com)**